

## DERMAPOLISH SHINE POLISHING

Ideal polish for repairing superficial scratches and waxing. Also known as ONE STEP (One step only), which makes it an indispensable product in the polishing process.

---

### HOW TO USE:

Distribute the product evenly on the polishing pad (high hardness). polish with slow movements applying moderate pressure. Once the process is finished, clean the surface with a high absorbency microfiber cloth.

The treatment can be applied either with a rotary or orbital machine at a speed between 1500 RPM and 2000 RPM.

---

### PRECAUTIONS:

Do not eat. Keep out of the reach of children. Do not use the product for uses other than those indicated and/or recommended. Do not mix or dilute with other products. Causes severe irritation. in case of accident or discomfort, consult a doctor immediately.

In the event of an accident, consult the Toxicological Information Service +34 915 62 04 20

### PROFESSIONAL USE

Always read the instructions.

**IMPORTANT:** This product contains hazardous substances at work so it is necessary always use the appropriate protective equipment. For further instructions, refer to the label of the product and safety data sheet. A person who uses the product for any purpose other than is the one recommended in this data sheet, you act at your own risk. It is the responsibility of the user

take all necessary measures to comply with local legislation.

Materials described are designed to be applied by trained professional personnel who use proper equipment and are not intended for sale to the general public.

The information and methods described are based on the best information and practices known to us and serve merely as guidelines for optimal use, without liability for performance, the results or suitability for any intended use. We do not accept any responsibility for the behaviour of the product or damages arising from the use of the product. Before using the product,

the user should check if this is the latest version.